

## Installing the appliance

Install the appliance in accordance with the installation guide within the instruction book supplied.

Once this step has been completed, ensure the appliance is working by controlling the appliance directly using the control panel.

Please take the time to read the program guides and functions as this will help you take full advantage of the features of your new appliance.

**Please ensure that the clock time is set before trying to enrol an oven.**

## Locating your Wi-Fi Password

Locate the Wi-Fi Password (WPA/WEP Key) which is normally found on the back of your Wi-Fi router.



If you are having trouble locating the Wi-Fi Password, please contact your Internet Provider.

## Making a note for later

Once you have your Wi-Fi Password, please make a note of it below as you will need this later on whilst connecting the appliance to the App.

Router Name

Password (WPA/WEP Key)

Connect your device to your Wi-Fi router ready to install the App

## Downloading the App

Download the Rosières E-PICURIEN App from the App store relevant to your device.


**Note** – The App is suitable for iOS (version 7 and greater) and Android (version 4 and greater)

App Name - Rosières E-PICURIEN




## Locating your product code

Locate the product code of your appliance with the help of the image below.



## Take note of the serial number

The illustration shows the format of the appliance information. Write your product serial number here below:




Serial number (16 digits):

\_\_\_\_\_

\_\_\_\_\_


## Step 1



Open the App Rosières E-PICURIEN. Create your account by tapping on "Sign-Up". Accept the privacy policy and complete the fields.

**Note** – You can explore all the features of the full E-PICURIEN range by tapping on "Demo".

## Step 2



In the homepage, tap on the appliance that you want to connect and tap on "Ok".

## Step 3



Insert the 16 digits serial number that you wrote down above and tap on "Next".

Check that the product details are correct and then tap on "Confirm".

## Step 4



Once your appliance has been recognized, tap on "Next".

Then, you have 5 minutes to complete the process; otherwise, you will need to start it again.

## Step 5



**On the appliance** – (1) Press "EXTRA" button until Wi-Fi icon is illuminated.

(2) Press the arrows until "RESET" appears on the display, then press "SELECT" button.

**On App** - Tap on "Next".

## Step 6



**Exit the Rosières E-PICURIEN app.**

**Go to your device Wi-Fi settings.**

## Step 7



In the list of available Wi-Fi networks, select "WIFIOVEN-xyzk".

If you do not find it, wait few more seconds or do a new scan.

## Step 8



**Exit from the settings of your device.**

**Return to the Rosières E-PICURIEN App** and wait for the App to detect the appliance. Once the "Wi-Fi Network is active" screen appears, tap on "Next"

## Step 9



Your home Wi-Fi Network will be automatically set by the App.

(If not, enter the name of your home Wi-Fi network, paying attention to lowercase and uppercase letters).

Insert the Wi-Fi Password (WPA/WEP Key), then tap on "Confirm".

## Step 10



For more advantages, you can **Register** your product by tapping the dedicated button.

Tap on "Start" to return in the App Homepage.

## Remote control mode



To enable remote control:  
(1) Press "EXTRA" button until Wi-Fi icon is illuminated.  
(2) Press the arrows until "ON" appears on the display, then press "SELECT" button.

## Other Quick Guide languages



<http://rosieresepicurien.com>

**If the set up does not complete** – It's important that there is a good Wi-Fi signal strength from the home router to the appliance: low Wi-Fi signal strength would cause the final stage of the set up to fail. To establish if this is the case, start the connection process again from Step 1; once at Step 8, place with your device (smartphone or tablet) next to the router and search for "WIFIOVEN-xyzk" net generated by the machine. If this does not come up as an option, this means the router cannot see the appliance. In this case, we highly recommend to bring the router near to the oven (if possible) or contact your internet provider and require the assistance to purchase a compatible "Wi-Fi Range Extender" to increase the signal strength.